



A2203

SERVICE PARTS LIST

THE M.G. Series MGA 1500

Item No.	DESCRIPTION	Commencing (E) GB101		Qty. per Vehicle		Unit of Issue	Type of Vehicle	MODIFICATIONS			REMARKS
		Part Number	Illus. No.	RHD	LHD			New Part Number	Change Point	Amdt. No.	
	<b>IGNITION EQUIPMENT</b>										
	<b>DISTRIBUTOR</b>										
1	Distributor	1H782		1	1			1H811	Com. (E) GB1809		Always use 1H811
2	Cover	17H5422	B1	1	1						
3	Condenser	17H5093	B2	1	1						
4	Contact set	17H5049	B3	1	1			17H5421 17H5423	Com. (E) GB1809		
5	Rotor arm	7H5086	B4	1	1						
6	Carbon and spring	17H5065	B5	1	1						
7	Dog—driving	17H5118	B6	1	1						
8	Plate—clamping	3H2138	B7	1	1						
9	Vacuum unit	17H5505	B8	1	1			17H5474	Com. (E) GB1809		
10	Clip—cover	17H5064	B9	2	2						
11	Cam	17H5066	B10	1	1						
12	Springs—automatic advance	37H5272	B11	1 set	1 set	1					
13	Toggle	17H5069	B12	2	2						
14	Weight	17H5095	B13	2	2						
15	Shaft and action plate	37H5273	B14	1	1						
16	Bushing	17H5071	B15	1	1						
17	Sundry parts	17H5106	B16	1 set	1 set	1					
18	Four-way spacer—cables	1G2673	B17	1	1						
19	Suppressor—ignition cables	3H1422	B18	4	4						
20	Lead—L.T. and spade terminal	27H5314	B19	1	1						
21	Screw for housing to distributor	52K2017	B20	2	2						
22	Washer for screw (spring)	LWN204	B21	2	2						
23	Washer for fixing plate to housing (plain)	PWN104	B22	2	2						
	<b>IGNITION COIL</b>										
24	Coil—ignition	1D1963	B23	1	1						
25	Nut—terminal	3H2695	B24	1	1						
26	Washer for nut	3H2696	B25	1	1						
27	Steady plate for coil	11G221	B26	1	1						
28	Bracket—steady plate/dynamo	1G2620	B27	1	1			1H1070 1H1302	Com. (E) GB29710 Com. (E) GB45905		Alternatives
29	Bracket—steady plate/dynamo			1	1						
30	Clamp bolt—bracket	HZS0406	B28	1	1						
31	Washer for clamp bolt (plain)	PWN204	B29	3	3						
32	Washer for clamp bolt (spring)	LWN204	B30	3	3						
33	Nut for bracket and clamp bolts	FNZ104	B31	3	3						

**SERVICE PARTS LIST**

**THE M.G. Series MGA 1500**

Item No.	DESCRIPTION	Commencing (E) GB101		Qty. per Vehicle		Unit of Issue	Type of Vehicle	MODIFICATIONS			REMARKS	
		Part Number	Illus. No.	RHD	LHD			New Part Number	Change Point	Amdt. No.		
	<b>VACUUM IGNITION CONTROL PIPE</b>											
1	Pipe—vacuum ignition control (with fuel trap)	1H830	B32	1	1			1H919	Com. (E) GB11301			
2	Clip	1K204	B88	1	1							
3	Nipple—carburetter end	2K6192	B94	1	1				Fin. (E) GB11300			
4	Tube nut—carburetter end	2K6193	B35	1	1			2A459	Com. (E) GB11301			
5	Olive	6K649	B36	1/2	1/2						Quantity increased at (E) GB 11301	
6	Tube nut—distributor end	6K650	B87	1	1	12						
7	Mounting clip for fuel trap	1H841	B38	1	1							
8	Bolt for mounting clip	PMZ0216	B89	1	1							
9	Washer for bolt (plain)	PWN102	B40	1	1							
10	Washer for bolt (spring)	LWZ202	B41	1	1							
11	Nut for bolt	CNZ102	B42	1	1							
	<b>H.T. CABLES, ETC.</b>											
12	Terminal—sparking plug	AEC388		4	4							
13	Cable—No. 1 H.T. (13" long)	45223	B43	A/R	A/R	100' roll						
14	Cable—No. 2 H.T. (10 1/2" long)	45223		A/R	A/R							
15	Cable—No. 3 H.T. (7 1/2" long)	45223		A/R	A/R							
16	Cable—No. 4 H.T. (9" long)	45223		A/R	A/R							
17	Sleeve—identity (No. 1)	2H4243	B44	1	1							
18	Sleeve—identity (No. 2)	2H4244		1	1							
19	Sleeve—identity (No. 3)	2H4245		1	1							
20	Sleeve—identity (No. 4)	2H4246		1	1							