



B 1437

SERVICE PARTS LIST

THE MGA 1600

Item No.	DESCRIPTION	Commencing (E) 16GA/H101		Quantity	MODIFICATIONS		REMARKS
		Part Number	Illus. No.		New Part Number	Change Point	
	IGNITION EQUIPMENT DISTRIBUTOR						
1	Distributor H.C.	1H811		1			
2	Cover	17H5422	1	1	57H5477		17H5422 not available; use 57H5477
3	Brush and spring	17H5065	2	1			
4	Condenser	17H5421	3	1	47H5250		17H5421 not available use 47H5250
5	Plate—contact breaker base	17H5469	4	1			
6	Terminal—bush and lead	37H5409	5	1			
7	Lead—low tension	17H5532	6	1			
8	Lead—earth	17H5531	7	1			
9	Contact set	17H5423	8	1			
10	Rotor arm	7H5086	9	1			
11	Dog—driving	17H5118	10	1			
12	Plate—clamping	3H2138	11	1		Fin. (E) 16GA/H31660	
13	Screw with nut			1	37H5063		
14	Vacuum unit	17H5474	12	1	47H5570		17H5474 not available use 47H5570
15	Clip—cover	17H5064	13	2			
16	Cam	17H5066	14	1			
17	Spring—automatic advance	37H5272	15	1 set			
18	Toggle	17H5069	16	2			
19	Weight	17H5095	17	2			
20	Shaft and action plate	37H5273	18	1			
21	Bushing	17H5071	19	1			
22	Sundry parts	17H5106		1 set			
23	Distributor			1	12H873		
24	Distributor				12H822	Com. (E) 16GC/H101	Not available; use 12H822
					12H458	Com. (E) 16GC/L1012, H4004	
					12H850	Com. (E) 16GC/H8422	
25	Cover		1	1	17H5422	Com. (E) 16GC/H101	Not available; use 57H5477
					57H5477	Com. (E.) 16GC/H8422	
26	Brush and spring		2		17H5065		
27	Condenser		3	1	47H5250		
28	Plate—contact breaker base		4	1	17H5469	Com. (E) 16GC/H101	
29	Terminal bush and lead		5	1	37H5409		
30					12H2639		
31	Lead—low tension		6	1	17H5532		For use with 12H873 and 12H458
32	Lead—earth		7	1	17H5531		For use with 12H822
33	Contact set		8	1	17H5423		
34	Rotor arm		9	1	7H5086	Com. (E) 16GC/H101	
35	Dog—driving		10	1	47H5249		
36	Vacuum unit		12	1	47H5570		
37	Clip—cover		13	2	37H5445		

SERVICE PARTS LIST

THE MGA 1600

Item No.	DESCRIPTION	Commencing (E) 16GA/H101		Quantity	MODIFICATIONS		REMARKS
		Part Number	Illus. No.		New Part Number	Change Point	
	Distributor—continued						
1	Cam		20	1	57H5047	Com. (E) 16GC/H101	
					57H5133	Com. (E) 16GC/L1012, H4004	
2	Spring—automatic advance		15	1 set	57H5406	Com. (E) 16GC/H101	
					57H5421	Com (E) 16GC/L1012, H4004	
3	Weight		21	2	57H5049	Com. (E) 16GC/H101	Not available; use 57H5420
					57H5420	Com. (E) 16GC/L1012, H4004	
4	Shaft and action plate		22	1	57H5050] Com. (E) 16GC/H101	
5	Bushing			1	47H5164		
6	Sundry parts		19	1 set	17H5106		
7	Plate—clamping		11	1	3H2188		
8	Screw with nut			1	37H5063		
9	Screw fixing distributor to housing	53K2017	23	2			Part No. Change was 52K2017
10	Washer—spring—screw	LWN204	24	2			
11	Washer—plain—screw	PWN104	25	2			
	IGNITION COIL						
12	Coil—ignition	1D1963	26	1	27H2204		1D1963 not available; use 27H2204
13	Nut—terminal	3H2695	27	1			
14	Washer for nut	3H2696	28	1			Standard model
15	Bracket—coil mounting	AHH15945	29	1			
16	Bracket—coil mounting			1	12H151	Com. (C) 91240	All round disc brakes model
17	Screw fixing coil to bracket	HZS0405	30	2			
18	Washer—plain—screw	PWZ204	31	2] Standard model
19	Washer—spring—screw	LWZ204	32	2			
20	Nut—screw	FNZ104	33	2			
21	Screw—clamp			1	HZS0416] Com. (C) 91240] All round disc brakes model
22	Washer—clamp screw and bracket (plain)			2	PWZ204		
23	Washer—clamp screw and bracket (spring)			1	LWZ204		
24	Nut—screw			1	FNZ104		
25	Washer—coil to dynamo bracket (plain)			2	PWZ205		
26	Washer—coil to dynamo bracket (spring)			2	LWZ205		
27	Nut—coil to dynamo bracket			2	FNZ105		

SERVICE PARTS LIST

THE MGA 1600

Item No.	DESCRIPTION	Commencing (E) 16GA/H101		Quantity	MODIFICATIONS		REMARKS
		Part Number	Illus. No.		New Part Number	Change Point	
H.T. CABLES							
1	Terminal—spark plug	AEC388	34	4			
2	Cable—H.T.—No. 1 13' (33-02 cm.)	AAA5981	35	A/R] Only available in multiples of feet Part no change; was 45223
3	Cable—H.T.—No. 2 10½' (26-67 cm.)	AAA5981	36	A/R			
4	Cable—H.T.—No. 3 7½' (19-05 cm.)	AAA5981	37	A/R			
5	Cable—H.T.—No. 4 9' (22-86 cm.)	AAA5981	38	A/R			
6	Sleeve—cable identity—No. 1	2H4243	39	1			
7	Sleeve—cable identity—No. 2	2H4244	40	1			
8	Sleeve—cable identity—No. 3	2H4245	41	1			
9	Sleeve—cable identity—No. 4	2H4246	42	1			
10	Sleeve—H.T. cable	8G596	43	1			
VACUUM CONTROL							
11	Pipe—ignition control	1H919	44	1			
12	Clip	12H90	45	1			
13	Olive—carburettor end	6K649	46	1			
14	Nut—carburettor end	2A459	47	1			
15	Olive—distributor end	6K649	48	1			
16	Nut—distributor end	6K650	49	1			
17	Clip—fuel trap mounting	1H841	50	1			
18	Bolt—clip	PMZ0216	51	1			
19	Washer—plain—bolt	PWZ102	52	1			
20	Washer—spring—bolt	LWZ202	53	1			
21	Nut—bolt	CNZ102	54	1			